



1. External Photograph of EUT

Model Name: PC40200(MWP6985)



Model Name: PC40200(MWP6985)



2. Photograph of Accessory

Model Name: PC40200(MWP6985)

List of Accessory:

Specification of Accessory		
AC Adapter 1	Brand Name	HTC
	Manufacturer	Foxlink
	Model Name	TC P300
AC Adapter 2	Brand Name	HTC
	Manufacturer	Delta
	Model Name	TC P300
Battery 1	Brand Name	HTC
	Manufacturer	TWS
	Model Name	BB96100
Battery 2	Brand Name	HTC
	Manufacturer	Formosa
	Model Name	BB96100
USB Cable 1	Brand Name	COXOC
	Model Name	DC M411
USB Cable 2	Brand Name	Foxlink
	Model Name	DC M411
LCM-Main	Brand Name	Sharp
	Model Name	LS038Y1LX02
LCM-2 nd source	Brand Name	Sony
	Model Name	ACX426AKM-7

Remark: For accessories equipped with this EUT, please refer to the following photos.

Model Name: PC40200(MWP6985)



Model Name: PC40200(MWP6985)

Adapter 1



Model Name: PC40200(MWP6985)

Adapter 2



Model Name: PC40200(MWP6985)



Model Name: PC40200(MWP6985)

Battery 2



Model Name: PC40200(MWP6985)

USB Cable 1



Model Name: PC40200(MWP6985)

USB Cable 2

