



ELECTRONICS

**SAMSUNG TELECOMMUNICATIONS AMERICA, INC.**

1130 East Arapaho Road

Richardson, TX 75081 USA

TEL 972-761-7987, FAX 972-761-7909

## Tune up Procedure - Indoor Mini-BTS

### **Tune-up procedure over the power range, or at specific operating power levels.**

1. Connect the serial cable to debug connector on the MXBB-1, MXBB-2
2. Execute the terminal program with following option 19200 bps, 8 bit, 1 bit, None
3. Change the attenuation of the XCVU-P (transceiver) using the command.

Command) `chg_att [attenuation_value]`

(cf: attenuation\_value:     0 ~ 600: attenuation 0 ~ 60.0 dB  
                              900 ~ 999: gain 0 ~ +9.9 dB

4. Measure the RF power of the output port placed on the AFEU-P rear panel.
5. Change the attenuation or gain with 0.1dB step using above command.