

M-70H HAND-HELD MICROPHONE PART-LIST

NO	Footprint	Comment	Quantity	Designators				
1	CHIP. CAP	104P	2	C2	C4			
2	CHIP. CAP	226P	1	C3				
3	CHIP. CAP	27P	2	C6	C5			
4	CHIP. CAP	475P	1	C1				
5	DIODE	IN5819	1	D1				
6	D20MMDIP6	PEC	1	PEC6				
7	D20MMDIP6	PEC	1	PEC1				
8	DSW2	PEC	4	PEC2	PEC3	PEC4	PEC5	
9	EC_LCD24	LCD	1	LCD1				
10	LED	LED	1	D2				
11	OSC2	4MHZ	1	Y1				
12	RES. CAP	222	1	R1				
13	RES. CAP	224	4	R3	R2	R4	R15	
14	RES. CAP	273	2	R5	R7			
15	RES. CAP	101	5	R8	R11	R12	R10	R6
16	RES. CAP	104	1	R9				
17	RES. CAP	103	2	R21	R17			
18	RES. CAP	223	5	R16	R18	R19	R22	R20
19	RES. CAP	332	1	R13				
20	RES. CAP	333	1	R14				
21	MICOM IC	PIC16C73	1	U2				
22	IC	C01A	1	U3				
23	TR	C1623	1	Q1				
24	IC	HT1621B	1	U1				

[illegible]