





NQ3TCP-CD


Computer Board (top)



Refer to the Installation/Operations Manual M906102 and the Specifications Bulletin S506025 for wiring and installation instructions.


NOTE: Ensure all power is removed PRIOR to alteration of field wiring.

NQ3TCP-00
Shield




NQ3TCP-CO

I/O Board (top)





NQ3TCP-00

Computer Board (bottom)




NQ3TCP-00
I/O Board (bottom)




NQ3TCP -CO

Enclosure w/o electronics



NQ3TCP-CO
Data Radio Board
(top)



NQ3TCP-CD
Data Radio Board
(bottom)



NR3TCP - CO
Antenna Assembly