


1. OPEN BATTERY COMPARTMENT

- PUSH AND SLIDE

2. BATTERY INSTALLATION



CAUTION :

- REPLACE BOTH BATTERIES OF THE VEHICLE AT THE SAME TIME.
- INSTALL BATTERIES IN THE COMPARTMENT ACCURATELY.
- AVOID MIXED USE OF MANGANESE AND ALKALINE BATTERIES.

3. HOW TO OPERATE

- TURN THE VEHICLE'S SWITH "ON"
- OPERATE THE VEHICLE WITH THE TRANSMITTER.
- PUSH BUTTON Δ ∇ OF THE TRANSMITTER TO GOES FORWARD AND TURNS LEFT IN REVERSE.
- WHEN THE PLAY IS OVER, TURN THE VEHICLE'S SWITH "OFF" AND REMOVE ALL BATTERIES BOTH FROM THE CAR AND THE TRANSMITTER.

FCC ID : NSD 9766W

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES.

OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:

1. THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
2. THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRDED OPERATION.

WARNING : THE PRODUCT CANNOT MODIFY THE TRANSMITTER.

CHOKING HAZARD - SMALL PARTS.

NOT FOR CHILDREN UNDER 3 YEARS.