

ANTENNA



KEYPAD

CPU

LCD

TUNER

SUPERREGENERATIVE
RECEIVER

Rx - RF MODULE

POWER
SUPPLY
CIRCUIT

AC / DC ADAPTOR
OR BATTERY
INPUT

WCID - R1000 BLOCK DIAGRAM