


## EUT PHOTOGRAPH

110ER-SR00-1P (Internal Antenna) Module


Module without Cover



## EUT PHOTOGRAPH


110ER-SR01-1P (External Antenna) Module

Module without Enclosure



## EUT PHOTOGRAPH

### Top View of RF Board without Shields



## EUT PHOTOGRAPH

### Bottom View of RF Board without Shields

