

ID label and location

Project: Simatic
Filename: Simatic_RF350M_ID_Label

Version: 1.2
Date: 07.04.2016

Prepared by: Sami Ruotsalainen
Checked by:
Accepted by: Hannu Heino


Distribution:
Change history:

Version:	Date:	Author:	Remarks:
1.0	26.1.2016	SRu	
1.1	2.2.2016	SRu	Updated outside labels
1.2	7.4.2016	SRu	Updated inside label

Table of Contents

1. SIMATIC RF350M MODEL 6GT2803-1BA00 OUTSIDE LABEL.....	3
2. SIMATIC RF350M MODEL 6GT2803-1BA10 OUTSIDE LABEL.....	3
3. SIMATIC RF350M MODEL 6GT2803-1BA00 INSIDE LABEL	4
4. SIMATIC RF350M MODEL 6GT2803-1BA10 INSIDE LABEL	4
5. SIMATIC RF350M LABEL LOCATIONS.....	5

1. SIMATIC RF350M MODEL 6GT2803-1BA00 OUTSIDE LABEL




Picture 1. Simatic RF350M label.

2. SIMATIC RF350M MODEL 6GT2803-1BA10 OUTSIDE LABEL




Picture 2. Simatic RF350M label.

3. SIMATIC RF350M MODEL 6GT2803-1BA00 INSIDE LABEL



Picture 3. Simatic RF350M inside label.

4. SIMATIC RF350M MODEL 6GT2803-1BA10 INSIDE LABEL



Picture 4. Simatic RF350M inside label.

5. SIMATIC RF350M LABEL LOCATIONS



Picture 5. Simatic RF350M outside label location.



Picture 6. Simatic RF350M inside label location.