



SYSTEM IN VEHICLE



SYSTEM FOR TEST



* Through the use of lamp, operating state is displayed by lamp.
lamp 'ON' means that actuator is operated by door lock or unlock or tail-gate output signal.

