





* Through the use of lamp, operating state is displayed by lamp.
 lamp 'ON' means that actuator is operated by door lock or unlock or panic output signal.

