









Internal Photo ( Model : Model : CG6640A )


































## Antenna A




## Antenna B





Adapter Photo ( Model : ML12-Y120100-A1)







**Adapter Photo ( Model : ML18-V120150-A1)**



