

Battery Care

1. Failure to insert batteries in the correct polarity may shorten the life of the batteries or cause batteries to leak.
2. Do not mix old and new batteries.
3. For best results, use alkaline batteries.
4. Do not mix Alkaline, Standard (Carbon-Zinc) or Rechargeable (Nickel Cadmium) or (Nickel Metal Hydride) batteries.
5. Do not dispose of batteries in fire.
6. Batteries should be recycled or disposed of as per manufacturer's recommendations.

30 DAYS LIMITED WARRANTY

FLIPO GROUP warrants to the original purchaser, when used in North America only, that this product shall be free of defects in material and workmanship. This warranty applies within 30 days of the original purchase with normal home use. This warranty does not apply for commercial use of this product. Use outside of North America is not covered by this warranty.

During the warranty period, we will at our option, repair or replace this product without charge, which shall be the consumer's sole remedy. ALL RETURNS must be accompanied by a Return Authorisation Number, which is issued by the Customer Service Department of Flipo Group. Please contact Customer Service BEFORE returning any item. Once you have obtained a Return Authorisation Number, the product must be returned with a clear copy of the proof of purchase, showing place and date of purchase, postage and insurance prepaid to:

Flipo Group
613 First Street
La Salle, IL 61301
Email: info@flipo.com
Website: www.flipo.com

This warranty does not cover installation, adjustments in the home, nor damage due to accidents, misuse, abuse, fire or other acts of God, incorrect line voltage, damage to other equipment caused by improper installation, unauthorized or improper modification. This warranty gives you specific legal rights and you may also have other rights that vary from state to state.

If you should have questions about your product's operation, battery installation, trouble shooting or just want to learn some interesting functions, please visit www.flipotv.com. Individual product videos can be found at either the page for your product located in the Toys Department or at the How To page.

****THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS.****

2010 Flipo Group Limited

Printed in China

FCC INFORMATION

This device complies with part 15 of the FCC Rule. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RC DASHER CAR OWNER'S MANUAL

Model No: 999G-17

- Ages: For 6 years old and above
- Please read the instructions carefully before beginning to play
- Adult guidance is strongly recommended

PLEASE NOTE

At Flipo Group we always want you to have fun "out of the box". We have included starter batteries to ensure that you can play with our toys immediately. For longevity and longer usage, we recommend you use alkaline batteries once the initial included batteries no longer work.

Transmitter

Remote Control Battery Installation.

1. Remove the screw holding the battery compartment door from the remote located on the rear of your remote control.
2. Remove the battery compartment door.
3. Insert one 9 volt battery according to the polarity information located in the compartment; make sure the (+) and (-) poles of the battery are positioned correctly.
4. Replace the battery compartment door and screw, and tighten screw completely to lock in place.


Car Battery Installation

1. Loosen the lock screw located on the bottom of your car; DO NOT REMOVE THE SCREW COMPLETELY! Once loosened, turn the fastener to the left and remove the battery compartment.
2. Insert 3 AA batteries according to the polarity information located in the compartment; make sure the (+) and (-) poles of each battery are positioned correctly.
3. Reinstall the battery compartment into the car. The compartment should be replaced with the two main battery poles inserted first and the compartment's lock tab located in the car's lock slot. PLEASE NOTE: The battery compartment will only fit properly if installed correctly. Once installed, turn the fastener to the right and retighten the lock screw.


OPERATION

1. Insert the end of the antenna with inner threads into the hole located at the top of the remote control. Once installed, turn clockwise to screw into place.
2. The car can be turned ON by moving the activation switch to either of the right positions. The car can be turned OFF by moving the switch back to the far LEFT position.
3. Drive the car by operating the sticks of the transmitter.




① FORWARD



② REVERSE



③ SPINNING STUNT MOVES



SAFETY RULES

- Not suitable for children under 6 years due to detachable small parts.
- Installation of the battery should ALWAYS be done by an adult.
- Keep fingers, hair and loose clothing away from the vehicle's tires and wheels.
- Don't pick up the vehicle while in motion.
- Don't put your vehicle or transmitter near any source of heat.
- Don't operate your vehicle in dangerous places.
- Avoid driving on sand and loose gravel.
- Don't let the vehicle get wet. Don't run through water or operate in the rain.
- Do not disassemble the vehicle or remote control.
- If the vehicle is damaged and any broken parts are exposed, the vehicle should not be used.
- Watch for and avoid obstacles.
- For best results, operate on hard flat surfaces. Operation on pliable surfaces such as carpeting or rugs may prevent some stunts.



WARNING

Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.