

# Lenovo Tab7

## Quick Start Guide


TB360ZJ

The Lenovo logo is positioned in the bottom right corner of the page. It consists of the word "Lenovo" written in a white, sans-serif font, oriented vertically within a dark grey rectangular background.

## Get started

- Read this guide carefully before using your device.
- All pictures and illustrations in this guide are for your reference only. The actual product may vary.

## Overview



- |                   |                |                |
|-------------------|----------------|----------------|
| 1 Volume buttons  | 2 Light sensor | 3 Front camera |
| 4 Charging light  | 5 Microphone   | 6 Speaker      |
| 7 USB-C connector | 8 Headset jack | 9 Card tray    |
| 10 Power button   | 11 Flash       | 12 Rear camera |

## Install cards

Turn off your device before inserting or removing a card.



- ⓘ If you're using a third-party SIM, contact your carrier for more details.

## Help and more

To get more information and download the *User Guide*, go to <https://support.lenovo.com>.

TB360ZJ: settings->About tablet->Legal information