



WOWee
ONETM
PRO

User Guide

Contents

Contents.....	2
User Guide.....	3
Included in This package.....	7
Technical Specification.....	8
Power Bass Portable Bluetooth Speaker.....	8
Troubleshooting.....	9
Safety Information.....	10
Important Handling Information.....	11
One Year Limited warranty.....	12
Regulatory.....	13

User Guide

1. Power On/Off

Press and hold the power button to turn the unit on and off. The GA logo will start to flash blue to indicate the unit is on.

(The unit will turn itself off after several minutes if not used or connected to)



2. Bluetooth Pairing

Once turned on, the unit automatically goes into pairing mode, shown by the GA logo flashing blue. To pair with the unit, search for 'WOWee Pro' using your bluetooth device and when selected will pair straight away, with no need for a password. Once paired the GA logo will stay solid blue to show a connection is made.



3. Bluetooth On/Off


If no bluetooth pairing is made after 3mins bluetooth is turned off. The GA logo turns solid white to show bluetooth is off. Press and hold the bluetooth button to turn back on. Alternatively if you wish to turn bluetooth off manually, press and hold this button until the GA logo turns white.



4. In Use

The unit uses the surface it is placed on to generate deep rich bass. Press the unit down slightly when positioned to ensure the unit has a good contact with the surface to achieve the best audio performance. Have fun trying it out on different surfaces for different sound performance.

** Please note the unit is not designed to stick and hold by itself onto vertical surfaces such as windows. Please see www.woweeone.com for accessories. **



Keep the base pad clean with a damp cloth to ensure a good contact is made with surfaces.



5. Answer / End Call

To answer any incoming calls press the button on the left side once to accept the call.

Press the button once again to end the call.

To reject an incoming call, press and hold the button until you hear a double beep.



6. Aux Input

To get sound from a device without bluetooth, just connect the two using the 3.5mm audio cable provided. The GA will change to solid white to indicate auxiliary input is being used.



7. Volume

To change volume, touch either the down or up white arrows. The unit will beep to indicate the volume level has changed. When the volume has reached the lowest level there will be no more beeps and when the unit reaches the highest level there is a double beep.



8. Muting

Touch both volume arrows together to mute the sound. Volume arrows will begin to pulse on and off to show mute is on. Press them both again, or just one of the arrows, to un-mute.

During a hands free call the mute function will disable the microphone so that the other person cannot hear you but you will still be able to hear them.



9. Low Battery

When the battery becomes low the battery indicator will appear red and start to pulse on and off. At this point please place the unit on charge by connecting the USB cable provided and then to a power source. The battery indicator will be solid red when charging and will turn off once fully charged.



Included in this package



- WOWee One™ Pro



- 3.5mm jack audio cable




- USB to micro USB re-charging cable

Technical Specification

- Playback Duration: Up to 10 Hours per charge
- Power: Built in rechargeable Li-Po Battery
- Charging input: Via micro USB typ. 5hrs
- Audio input: 3.5 mm audio jack
- Output Power: 2W RMS
- Frequency Range: 40Hz – 20KHz

Power Bass Portable Bluetooth Speaker

- 1. Bluetooth Button / Answer & End Call
- 3. GA function Indicator
- 5. Power Button
- 7. Aux Input Socket
- 9. USB Charging Socket
- 2. Volume Down
- 4. Volume Up
- 6. Battery Indicator
- 8. Mic
- 10. Gel Pad



Troubleshooting

No LEDs light up when trying to turn the unit on:

The battery could be out of power and needs recharged.

Connect the unit to a power supply and fully charge the unit.

No sound:

Check the unit is switched on.

Make sure the unit is paired properly via bluetooth to the audio source.

Make sure the unit or audio device isn't on mute.

Make sure the volume is turned up on both the unit and audio device.

Check 3.5mm audio jack is inserted correctly if being used.

Can't connect to the unit via Bluetooth:

Check that bluetooth is switched on both the unit and audio device.

Clear the unit as a device on your phone/mp3 and attempt to establish a brand new pairing with the unit.

Unit is moving:

Clean the bass pad.

Lower the volume level as the bass may be too strong.

Lack of bass:

The surface the unit is on is too dense to allow the sound vibrations transfer through, therefore try and move the unit onto a less dense and thick surface.

Safety Information

WARNING

Failure to follow these safety instructions could result in damage to WOWee One™ Pro or other property.

Fire, Electric Shock and Damage Hazard

- Do Not expose WOWee One™ Pro to rain, water, liquid or moisture to reduce the risk of electric shock.
- Do Not drop, disassemble, open, crush, bend, deform, puncture, shred, microwave, incinerate, paint, or insert foreign objects in to WOWee One™ Pro.
- Do Not place WOWee One™ Pro near radiators, near fire sources, under direct sunlight or near water to avoid damages.
- Do Not place WOWee One™ Pro directly onto hard drives or other devices affected by magnetic fields. Magnets are used in this product
- Do Not store or expose WOWee One™ Pro to extreme temperature. Acceptable temperature is between -10° and 60° C (14° to 140° F).
- Do Not operate WOWee One™ Pro in too cold or too hot environment. Suitable environment temperature is between 0° and 45° C (32° to 113° F).

Battery/Charger Hazard

- Do Not dispose WOWee One™ Pro in a fire. The battery could explode causing injury or death.
- Do Not charge WOWee One™ Pro in damp area or in extreme temperature.
- Must only use a Certified USB Power Adapter if main power is used as power source.

Fall Hazard

- Do Not place WOWee One™ Pro on vertical surfaces like window or wall on its own. Go to www.woweeone.com for accessories.
- Do Not place WOWee One™ Pro on high surfaces like shelves. During music, WOWee One™ Pro might shift and fall if the base pad is dirty,

Important Handling Information

Caution

Failure to follow these handling instructions could result in damage to WOWee One™ Pro or other property.

- Operate WOWee One™ Pro in a place where the temperature is between 0° and 45° C (32° to 115° F). Battery life might temporarily shorten in low-temperature conditions.
- When using WOWee One™ Pro or charging the battery, it is normal for WOWee One™ Pro to get warm. The exterior of the unit functions as a cooling surface that transfers heat from inside the unit to the cooler air outside.
- Do Not store WOWee One™ Pro in a discharged state for prolong period. This may cause irreversible failure to the battery.
- Do Not use abrasive cleaner to clean WOWee One™ Pro because this could cause scratches or damage.
- Do Not force a connector into a port. Check for obstructions on the port. Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.
- Do Not attempt to repair or modify WOWee One™ Pro yourself. It does not contain any user-serviceable parts.
- Do Not attempt to replace WOWee One™ Pro battery. It is built in and not changeable

One Year Limited Warranty

Thank you for purchasing WOWee One™ Pro, a rechargeable portable bluetooth speaker which has been designed and manufactured to the highest quality standards. This limited warranty applies, provided the product is handled properly for its intended use and in accordance with its operating instructions.

This limited warranty does not apply to:

- 1) Product repair or product modifications and alterations that has been executed by unauthorised service organisations or persons.
- 2) Damaged product that caused by accident, abuse, misuse, fire and natural disasters.
- 3) Damaged product that cause by operating the product outside its intended use.

In case your WOWee One™ Pro is not working properly, please contact :

Email: info@woweeone.com www.woweeone.com

All rights reserved. Reproduction in whole or in parts is prohibited. The Gel Audio trademark is operated under a worldwide licence by SFX Technologies Limited.

Regulatory

Disposal of WOWee One™ Pro

The crossed-out wheeled bin symbol on the base pad indicates that this product is covered by the European Directive 2002/96/EC.



The battery is not replaceable and it needs to be removed and disposed responsibly.

All electrical and electronic products must be collected separately by your local collection system. Please act accordingly to your local rules and do not dispose of your old products with your normal household waste.

Removal of Battery

Wedge under the grill using a flat screwdriver and prise off the top plate. Remove the battery from WOWee One™ Pro and dispose the battery responsibly.

EU Declaration of Conformity

CE0700

This product is in compliant with the CE directive. For the Declaration of Conformity, visit website www.woweeone.com

FCC Compliance Statement

This device has been tested and found to be comply with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Do not make changes or modify the device in any way. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC ID: O5QWOPRO

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

for accessories, support
and more products please visit.....

www.woweeone.com



© 2012 WOWee ONE™. All rights reserved.
Gel Audio™ & GA logo are trademarks of SFX Technologies LTD.

