

Photo 1: Internal photo of EUT



Photo 2: Internal photo of EUT




Photo 3: Internal photo of EUT




Photo 4: Internal photo of EUT



Photo 5: Internal photo of EUT

Antenna



Photo 6: Internal photo of EUT

Wireless module




Photo 7: Internal photo of EUT

Wireless module




Photo 8: Internal photo of EUT

Wireless module



Photo 9: Internal photo of EUT

Battery



Photo 10: Internal photo of EUT

Battery

