



BT 1000 USER GUIDE

Air Sound-BT1000



About your speaker

With the GDMALL BT1000 wireless speaker, you can listen to music from your compatible device, such as a phone or music player, and enjoy high-quality audio. A single speaker fills your room with music, and you can connect a second GDMALL BT1000 wireless speaker for stereo sound. You can connect to another device on the go, without stopping the music playing. The speaker also has a standard 3.5 mm audio connector.

Read this user guide carefully before using the product. Also, read the user guide for the device that you connect to the product.

About Bluetooth

You can use Bluetooth to wirelessly connect devices and accessories to other compatible devices, such as phones. Devices do not need to be in direct line-of-sight, but they must be within 10 metres (33 feet) of each other. This device is compliant with Bluetooth Specification 2.1 + EDR supporting the following profiles: A2DP, AVRCP. Check with the manufacturers of other devices to determine their compatibility with this device.

⚠ This product may contain small parts. Keep them out of the reach of small children.

Get started

IF THE LED RING IS... 5

Flash Green

The 2 speakers are connected

Flash Blue

BT1000 is in pairing mode and ready to connect to your phone or Bluetooth® device. Go to your phone's Bluetooth® settings to connect.

Flash Red

Battery is low. Power up!



- 1 Volume up key
- 2 Play and Pause key
- 3 M-Touch to tell left or right channel
- 4 Volume down key
- 5 -Bluetooth status indicator
-Battery status indicator
-Bluetooth pairing key

- 6 Bass Tube
- 7 Charger connector
- 8 3.5 mm audio input connector
- 9 Power key
- 10 Charger indicator

Charge the battery

Before using the speaker, you must charge the battery.

When the battery level of the speaker is low, the battery indicator red light flashes 5. When the battery is charging, the charger indicator stays on red 10. After the battery has fully charged, the red light switches off 10.

NOTE It takes 3 hours to give your BT1000 A full charge.

- 1 Connect the charger to a wall outlet.
- 2 Connect the charger cable to the charger connector on the speaker.
- 3 When the battery is fully charged, first disconnect the charger from the speaker, then from the wall outlet.

You can also use a compatible USB cable to charge the battery. Charging over USB can take longer to start and you may not be able to use the speaker immediately. Charging may not work if you connect through a non-powered USB hub. Your speaker charges more quickly when connected to a wall outlet. You can only use the USB connection to charge the battery.

Switch the speaker on

Press and hold on both speaker's power key for **2 Sec** to power on until the LED turn Blue, these two speakers will connect each other automatically, and you will heard the "**left channel**" and "**right channel**" sound from each speaker while you touch the "M" key.

If you already have paired the speaker with one or more devices, the speaker connects to the last device it was used with. If the speaker can't connect to the last used device, it connects to the next device on the paired devices list.

If the speaker is not connected, standby mode is activated, and the Bluetooth status indicator light turns blue (Blue LED flash1 times/2sec, constantly). If the speaker is not connected to a device within 5 minutes, the speaker switches off.

PREPARE YOUR PHONE OR DEVICE Turn on Bluetooth®.

ON AN IPHONE®, IPOD®, OR IPAD®

Go to SETTINGS > GENERAL > and enable BLUETOOTH

ON A BLACKBERRY®

Go to SETTINGS/OPTIONS >BLUETOOTH and enable BLUETOOTH

ON A NOTEBOOK

Click "bluetooth manager" , active function of Bluetooth to serch "BT1000". Once pairing completed, please check whether notebook detect and ready Speakers. Go-Control panel, Go-Sound, and find an extra speaker.

Pair your device

Before using your speaker with a compatible device, such as a phone, for the first time, you must pair and connect it to the device.

1. Please press and hold the bluetooth pairing key (**Left Channel speaker**) for 2 sec. (Pairing Mode-Blue LED flash2 times/0.5sec, constantly.) You can touch the "M" Key to know which speaker is left.
2. Within 3 minutes, activate Bluetooth on the compatible device, and set it to search for compatible devices.
- 3 Select the speaker from the list of found devices.(BT-1000)
- 4 If required, enter the passcode 0000.
- 5 When the pairing is connected, the Bluetooth indicator LED flashes blue twice every 2 SECS, constantly.)



Left Channel

When the speaker is paired, the Bluetooth status indicator light is blue.

If the connected device leaves Bluetooth range, the speaker tries to reconnect for 5 minutes. If the device returns within range, the speaker reconnects automatically.

The speaker remembers which channel it has been when paired with different speakers. When the speakers are paired, you can adjust the volume level / Play and Pause or switch both speakers off from either speaker.

You can only pair and connect your device to the speaker that is the left channel. The speaker that is the right channel is not in the paired devices list in your phone.

Connect to 3.5 mm audio

You can also use a standard 3.5 mm audio cable to connect your device to the audio connector  in the speaker.

 **Warning:**

Continuous exposure to high volume may damage your hearing. Listen to music at a moderate level.

Listen to music

Enjoy your favourite music with your friends. Connect a compatible device, such as your phone, to your speaker, and start playing music.

Mono Mode/ Stereo Mode

If you turn off one, the other speaker will change to stereo mode automatically.



Left



Right

OR






Stereo Mode

Manually Pairing left and right Channel

The speakers are already pre-paired at the factory. if not, you can pair the speakers manually by following:

Press and hold on both speaker's power key for **5 Sec** until the led ring turn from blue to flash **Green**. And then the Green LED will flash 1 time /sec, constantly for both of the speakers.(2 Speakers pairing). When the 2 speakers is connected, you will hear the BT1000 say left channel and right channel from each speaker when you touch the "M" key, and the LED will turn to blue. Then you are ready to pair to your bluetooth device.



 **Battery/Charger Hazard**

- Do not dispose of your Speaker in a fire. The battery could explode causing injury or death.
- Only charge the battery in accordance with the user instructions supplied with the BT1000 Speaker.
- Do not attempt to disassemble the Speaker charger or force open the built-in battery because this may result in electric shock.
- Do not charge the Speaker in damp areas or in extremely high or low temperatures because this could result in electric shock.
- Do not clean the Speaker when it is being charged. Always unplug the charger first before cleaning the Speaker.

Federal Communications Commission (FCC) Statement

You are cautioned that changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation of the device.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.