

User Manual

BLUETOOTH ADAPTOR 藍芽接收器 M1000N

SAFETY



CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.

The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying this home theatre.

WARNINGS:

To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

DO NOT REMOVE COVER or OPEN THE CABINET.
Dangerous high voltages are present inside the enclosure. No user serviceable parts inside. Refer servicing to qualified personnel only.

Use of controls, adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.

Package Contents

- 1 x Bluetooth music receiver
- 1 x USB Cable
- 1 x Quick Start Guide

SPECIFICATIONS

Bluetooth version	■ Bluetooth V 3.0
Bluetooth profile	■ A2DP
Frequency response	■ 2.4GHZ-2.4835GHZ
Receiving sensitivity	■ -74±4dB
Effective range	■ Up to 10m
Charging input voltage	■ DC 5V
Lithium battery	■ 200mAh
Working time	■ Up to 10 hours
Charging time	■ About 2 hours
Dimension	■ 78*78*20mm
Weight	■ 20g

Feature

- Turn your favorite speakers into a wireless sound system for your smartphone or tablet.
- Building NFC function for easy pairing.
- Build in battery, up to 12 hours working time, 230 hours standby time.
- Stream stereo audio instantly from any Bluetooth smartphone or tablet. Your mobile device stays mobile, and you have the freedom to move around with it.
- The GDMALL Bluetooth Adapter works with any device with a regular sized headphone jack (3.5mm).
- The M1000 produce a bass-rich Bluetooth music experience with any regular Bluetooth music device.


Overview

Start here

Important Safety Instructions

1. Read and keep these instructions carefully.
2. Heed all warnings.
3. Follow all instructions.
4. Do not use this device near water.
5. Unplug this device when unused for long period of time.
6. This device may contain small parts, keep them away from the reach of children.
7. Servicing is required when the device has been damaged in any way, such as liquid has been spilled into the apparatus, connector or plug is damaged, etc.

Setting up your Bluetooth Music Receiver



Connection



Function

PAIRING WITH NFC ENABLED DEVICE

1. CONNECTING BLUETOOTH ADAPTER TO STEREO SYSTEMS

Connect the Bluetooth adapter to an audio in (non-Bluetooth stereo system/headphone etc) with a 3.5mm audio connector. Connect one end with the Bluetooth adapter and the other end to the stereo systems.

2. TURNING ON YOUR DEVICE'S NFC

For NFC enabled devices – turning on your compatible device's NFC

3. PAIRING

After turning on your device's NFC function, tap your device's NFC tag to the Bluetooth adapter's NFC area (top of the Bluetooth adapter). When they are connected, you'll hear an indication sound.



4. PLAY MUSIC FROM YOU DEVICE.

Although the Bluetooth adapter can only play music from one device at a time, it's capable of being paired up to eight devices. Now your Bluetooth adapter is now connected and ready to play music.

5. DISCONNECTING CONNECTION AND TURNING OFF THE BLUETOOTH ADAPTER.

Tap your device's NFC tag to the Bluetooth adapter's NFC area again to disconnect. To turn off the adapter, press and hold the power button, for about 5 sec, until you see the Blue LED at top fades.


PAIRING WITH NON- NFC DEVICE

1. CONNECTING BLUETOOTH ADAPTER TO STEREO SYSTEMS

Connect the Bluetooth adapter to an audio in (non-Bluetooth stereo system/headphone etc) with a 3.5mm audio connector. Connect one end with the Bluetooth adapter and the other end to the stereo systems.

2. ENTERING PAIRING MODE FOR NON-NFC DEVICES

* Bluetooth adapter must be off before going into pairing mode for non-NFC devices.
Press and hold the power button until you see the blue light flashes, you'll hear the indication sound, continue holding it until the LED starts to blink.



3. TURNING ON YOUR DEVICE'S BLUETOOTH For Non-NFC Devices – Turning On Your Compatible Device's Bluetooth

Using iPhone, iPad, iPod
Go to Setting -> General Setting -> Turn on Bluetooth

Using BlackBerry
Go to Setting/ Option -> Turn on Bluetooth

Using Notebook
Go to Bluetooth manager, turn on Bluetooth and search for M1000N. Once pairing is complete, check whether the notebook is set to connected speaker.

4. PAIRING


After turning on your compatible device's Bluetooth, search for new device and connect to M1000N, when connected, you'll hear the indication sound.

5. PLAY MUSIC FROM YOU DEVICE.

Although the Bluetooth adapter can only play music from one device at a time, it's capable of being paired up to eight devices. Now your Bluetooth adapter is now

FOR SPEAKERPHONE

For Speakerphone, press the Power button/ Speakerphone/ Pairing button when you've received a call on your mobile device.



My music is not coming out

solutions:

- Make sure the Bluetooth Music Receiver is powered.
- Make sure an audio cable is correctly and firmly connected to the Bluetooth Music Receiver.
- Make sure the stereo volume is set to a comfortable listening level.

FCC Warning statement

a. for FCC 15b devices (15.105)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

b. FCC Part 15.21 information for user

You are cautioned that changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

c. FCC Part 15.19

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation