


**FCC ID: O8KAK-1  
MODEL: AK-1  
INSTRUCTIONS**

**SPECIFICATIONS:**

Frequency: 49.82-49.90MHz.

Battery size: 1X6F22 (9V)



- 1. ANTENNA
- 2. SPEAKER
- 3. TALK SWITCH
- 4. VOLUME CONTROL AND  
ON/OFF SWITCH

- 5. CODE KEY
- 6. BATTERY DOOR
- 7. BELT CLIP

**Operations**

- Open the battery door (6), then insert a 9V battery.
- Close the battery door (6).
- Switch the unit on by turning ON/OFF switch (4) and adjust volume by tuning the volume control (4).
- Send signals by pressing the code key (5).
- Push the talk switch (3) for talking, release the talk switch (3) for receiving.

**CAUTIONS**

Weak battery can leak and severely damage the unit.

Always remove battery when the unit will not be used for a long time.

Replace battery immediately when it becomes weak.

**Remark:**

User cannot modify this product.