


USER'S MANUAL

OPERATING INSTRUCTION FOR THE ENERGY SAVING LAMP TME15W,20W,25W

- 1,THE DEVICE COMPLIES WITH PART 18 OF THE FCC RULES.
- 2,USE ONLY ON 120V 60HZ CIRCUITS.
- 3,USE ONLY WITH A PORTABLE TABLE LAMP THAT IS PROVIDED WITH A SHADE.
- 4,THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXIT FIXTURES OR EMERGENCY EXIT LIGHTS.
- 5,NOT FOR USE ON DIMMING CIRCUITS.
- 6,NOT FOR USE IN TOTALLY ENCLOSED RECESSED FIXTURES.
- 7,USE IN DRY LOCATION ONLY.
- 8,INSTALL AND REMOVE LAMP FROM FIXTURE BY GRASPING PLASTIC BASE.



- 9,THIS PRODUCT COULD PRODUCE INTERFERENCE WHEN USE NEAR TV, RADIO, WIRELESS REMOTE CONTROL OR MARINE SAFETY COMMUNICATIONS EQUIPMENT OR OTHER CRITICAL NAVIGATION OR COMMUNICATION EQUIPMENT OPERATING BETWEEN 0.45~30 MHz. IF INTERFERENCE SHOULD OCCUR, MOVE THE LAMP AWAY FROM THE APPLIANCE INTO A DIFFERENT OUTLET.