

## Troubleshooting

VR Scape does not work by itself.

It works as a plugged-in software on the Internet Explorer or the Netscape Navigator.

When you use this software on the Internet Explorer, set low safty level at the System Security Option.

If a warning message is showed up, you can ignore it.

Because it results from different environment of its computer.

And it does not cause any problems with your computer.

### **1. Image does not appear on the monitor.**

- Is the SFC-2000 correctly connected between the monitor cable and the VGA port ?
- Is the power cord disconnected ?

### **2. The goggle is functioning properly, but the image is not stereoscopic.**

- Check the reverse switch of the IST-2000

### **3. The goggle is not working.**

- Check the power switch of the IST-2000
- Check the battery
- Are the legs of the goggle unfolded ?

### **4. Image is flickering**

- Set the vertical frequency of VGA card to maximum level if possible

### **5. If you have a AT type keyboard**

- You need a AT type product, or consult to your local dealer

## ● **WARRANTY**

Another World warrants the replacement or repair of all parts of this product, which is proved to be defective material or workmanship for one year.

## **TERMS and CONDITIONS**

This warranty applies only to the first purchaser use when the product has been properly installed according to the instruction supplied by Another World.

Another World is not liable for any claims or damages resulting from repair or attempted repair by anyone not authorized by Another World.

Damage due to abuse, accident(including natural disasters), shipment, unauthorized product modification, and the use of supplies of parts not meeting with Another World's specification and regulation cancels all obligations of this warranty.

This warranty does not cover expense readily accessible for servicing.

Names of products mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective companies.

## ● **SPECIFICATIONS**

### **1. Another I's(Wireless LCD shutter goggle)**

- . Weight : 3.52 oz (100 gram)
- . Max Frequency : 180 Hz
- . Receiving Angle : 60 Degree
- . Battery Life : 200 Hours
- . Battery Type : 3V (CR2032) lithium Battery X 2EA

### **2. IST-2000(IR Transmitter)**

- . Effective emitting Angle : 120 Degree
- . Cable Length : 6.56 ft
- . Size : 28 X 42 X 16mm
- . Weight : 0.28 oz (8 gram)
- . Power ON / OFF Switch
- . Reverse Left / Right Switch
- . Operating Distance : 16.4 ft

### **3. SFC-2000(VGA pass-through Adapter)**

- . Size : 50 X 70 X 18mm
- . Weight : 1.23 oz (35 gram)
- . Connector : Standard VGA port / Keyboard connector

### **4. Keyboard pass-through Adapter**

- . Length : 0.45 ft
- . Weight : 0.7 oz (20 gram)
- . Voltage : 5V

### **5. CD contents**

#### **Software**

- VR Pic** - Stereoscopic still image viewer
- VR Stream** - Stereoscopic moving image viewer
- Stereoshop** - Stereoscopic image editor
- VR Scape** - Stereoscopic converting software for VRML 97 format
- 3D Gallery**

## System Requirements

- IBM compatible computer using a CRT monitor
- Pentium 100MHz  
16MB RAM
- Standard VGA  
(VGA card supporting Open GL recommended)
- Double speed CD-ROM drive



### CONTACT SERVICE

Email : support@anotherworld.to

Tel : 82-335-337-2468 / Fax : 82-335-337-2469

If you have any comment,

contact Another World, Inc

Technical Service

We will continually provide updated  
contents to our customers throughout  
Another World, Inc. on web site

<http://www.anotherworld.to>