


## 2. Description for GVP unit

### ❖ Front View ❖



- **CCD Camera:** Capture your image.
- **LCD Screen:** Display the other party and your image
- **Power Indicator:** When Power Indicator is on, it indicates that power is connected to videophone.
- **Monitor Indicator:** Light when LCD Screen is activated or blinking at Auto-Answering(Remote Surveillance) mode
- **Speaker:** You can hear the other party's sound through this.
- **Keypad :**
  - ⓐ Number / Alphabet  
Entering phone numbers & characters
  - ⓑ For switching number key / Alphabet key
  - ⓒ Exit GUI mode
  - ⓓ Requesting video communication in audio mode
  - ⓔ For switching various screen mode
  - ⓕ Block the outgoing audio
  - ⓖ Block the outgoing video
  - ⓗ For hand-free dialing
  - ⓘ Up/Down or Left/Right option select
  - ⓙ Enter the GUI mode or Confirm the selected mode