


**Volume control :** Push the (+) to increase volume and the (-) button to decrease volume.


**NOTE :** When connected to a Mobile Phone, if you push the , the first track in your music library will begin to play. This function is disabled during an incoming call.





**Connecting to a Device via 3.5mm~AUX IN~ Input**

You can use unplug-100 Music Bluetooth Speaker for music playback with and device that has 3.5mm headphone port. You will need a 3.5mm to 3.5mm mini jack cable.

Simply plug one end of the cable into your device, as you would to a pair of headphones. Plug the other end of the cable into the 3.5mm port marked "AUX" on the back of unplug-100 Music Bluetooth Speaker.



Play music.





<p><b>Taking Calls on a Mobile Phone Connected to unplug-100 Music Bluetooth Speaker</b></p> <p>When you receive an incoming call, ring tone will sound from unplug-100 Music Bluetooth Speaker. If you are listening to music through your Mobile Phone the music will automatically pause.</p> <p><b>To accept a call:</b> You can accept a call as you usually do, using your Mobile Phone controls or touch the  on the top of unplug-100 Music Bluetooth Speaker. Speak normally. Your call will come through the speakers and your voice picked up through the built-in mic.</p> <p><b>To end a call:</b> Use your Mobile Phone controls or press the  button.</p> <p><b>To reject a call:</b> Use your Mobile Phone controls or press and hold the  button.</p> <p><b>To use call waiting:</b> Use your Mobile Phone controls or press and release the  button twice in succession to put the first call on hold and answer the incoming call. Repeat to switch back to the first call.</p>	<p><b>LED Indicator</b></p> <p>There is an LED light in the middle of the front Bluetooth Speaker. Below are what the LED's various displays indicate.</p> <p><b>LED off</b> - Power OFF</p> <p><b>BLUE</b> - Power ON</p> <p><b>Flashing BLUE/RED</b> - Pairing mode</p> <p><b>Quick Flashing Red with Tone Sound</b> - Low Battery Level</p> <p><b>Flashing RED</b> - When Charging</p> <p><b>Flashing BLUE</b> - Device Paired</p> <p><b>Set-Up and Pairing via Bluetooth For Music Playback and Hands-free Calling</b></p> <p>NOTE: unplug-100 Music Bluetooth Speaker can pair with most Bluetooth 2.0 devices. Pairing may vary by device. Consult your Bluetooth device's manual for pairing instructions.</p>
--	---

<p><b>NOTE:</b> Not all PCs support all Bluetooth profiles needed for full functionality with unplug-100 Music Bluetooth Speaker. Your PC may need additional Bluetooth drivers or profiles installed. Please consult your owner's manual. If your PC does not support needed Bluetooth profiles, you can connect with a 3.5mm to 3.5mm minijack cable and listen to music through unplug-100 Music Bluetooth Speaker. See section Connecting to a device via 3.5mm "AUX IN" input.</p> <ol style="list-style-type: none"> <li>1. Put unplug-100 Music Bluetooth Speaker into pairing mode.</li> <li>2. On you PC, click "Start" then click "Control Panel".</li> <li>3. Under "Hardware and Sound" click "Add a device".</li> <li>4. The Add a Device Wizard will pop up. You should see an icon for "unplug-100". Click on it and then click "Next".</li> </ol>	<ol style="list-style-type: none"> <li>2. Set your Bluetooth device to "discover" the unplug-100 speaker, then locate the Bluetooth Device list.</li> <li>3. From the Bluetooth device list, select the device named "unplug-100".</li> <li>4. If your device asks for a passkey, enter digits 0000 (four zeros) and press OK. Some devices Also ask you to accept the connection.</li> </ol> <p>Your Bluetooth device indicates when pairing is complete. The unplug-100 speaker indicates pairing is complete when the LED indicator turn flashing Blue with tone sound.</p> <p><b>To connect a device</b></p> <p>To connect a previously paired device ,press the Bluetooth button on the unplug-100 speaker. The Bluetooth indicator on the speaker flashes on and off approximately twice every second until the device connects. Then the indicator stops flashing and remains steadily on when the speaker and device have successfully connected.</p>
---	---

[illegible]

<p><b>Features and Benefits</b></p> <ul style="list-style-type: none"> <li>• Bluetooth 2.1 with Westinghouse audio digital signal processing Technology for clean, best-in-class wireless stereo sound reproduction</li> <li>• Built-in mic with advanced noise-cancellation enables clear wireless hands-free calling and conferencing</li> <li>• Two 40mm full range drivers deliver superb music fidelity</li> <li>• Ultra Bass Booster Passive Radiator Subwoofer</li> <li>• Convenient charging with included mini USB charging cable</li> <li>• Rechargeable Lithium Ion battery for up to 6 hours of playtime</li> <li>• Connects to iPod® or any device with a 3.5mm headphone port using a mini jack cable</li> <li>• Auto-search and auto-reconnect with compatible device</li> </ul>	<p><b>Controlling Volume When Connected via 3.5mm™ AUX™ Input:</b></p> <p>NOTE: Volume cannot be controlled with the volume control on unplug-100 Music Bluetooth Speaker when connected via the 3.5mm™ "AUDIO IN" input. Use the volume control on you device as you normally would.</p>  <p><b>Recharging Battery</b></p> <p>Make sure the power switch is set to "ON". Plug the Mini USB end of the included USB cable into USB mini port, Marked "USB" on the back of unplug-100 Music Bluetooth Speaker. Plug the other end into a USB port on your computer or Power adaptor. Charge time is 4hrs from an empty battery.</p> <p><b>NOTE:</b> Always be sure to switch unplug-100 Music Bluetooth Speaker to the "OFF" position when not in to use to save battery charge.</p> 
---	--


<p><b>Compatibility</b></p> <p>Wireless: Devices with Bluetooth 2.0 or above(See General Specifications for profiles), Bluetooth equipped PCs and most Bluetooth equipped smartphones or computers.</p> <p>Wired: Devices with a standard 3.5mm headphone output port via 3.5mm mini jack cable.</p> <p><b>⚠ WARNING</b></p> <ol style="list-style-type: none"> <li>1. Do not leave the product exposed to a heat source or high temperatures.</li> <li>2. Do not remove or attempt to remove the non-user-replaceable battery.</li> </ol> <p>When disposing of the product,take it to a waste electronics service.</p>	<p><b>Controlling iPod or Bluetooth PC or music phone's music Playback on unplug-100 Bluetooth speaker</b></p> <p>In Addition to using the playback control on your iPod or Bluetooth equipped PC or music phone as you normally would, you can control music playback from unplug-100 Music Bluetooth Speaker using the touch  buttons.</p> <p><b>NOTE :</b> Your device must support AVRCP (Audio Video Remote Control Profile) to control your device's from unplug-100 Music Bluetooth Speaker. Please check your device's owner's manual. At this time, Apple devices equipped with Bluetooth, like iPhone, iPad and Macs, do not support AVRCP.</p> <p><b>Play/Pause:</b> Push and release the  button to play/pause.</p>
---	---

**Pairing with Bluetooth devices**

Pairing occurs when two Bluetooth devices communicate with each other and establish a connection. A record of information about this connection is then stored in the memory of each device. Once you pair a device with the unplug-100 speaker, you should not have to pair it again.

The unplug-100 speaker can pair with up to six Bluetooth devices. However, it can only connect to, and play audio from one device at a time.

**To begin pairing with a Bluetooth device**

1. With the Bluetooth device and the unplug-100 speaker both turned on, Touch and hold the  button (Fig.1) on the speaker for two seconds to make the speaker discoverable. The LED indicator on the unplug-100 speaker LED indicator Flashing Red and Blue, approximately once every second to show that the speaker is discoverable.

说明书	103.0 mm
规格：103x70mm	
页数:20p（含封面）	
纸质及印刷色彩：封面封底 128g铜版纸 光膜 4色印刷；	
内页 80g 普通纸 黑白印刷。	