

badasheng

Optical wireless gaming headset instruction manual

Item name : 5.8G optical wireless gaming headset

BDS-888W



Contents

English 02-21

Français 22-41

Español 42-61

Deutsch 62-81

Italiano 82-101

日本語 102-121

English



Optical wireless gaming headset instruction manual

Item name : 5.8G optical wireless gaming headset



1, Product & accessories :

- A, Headset -----1PCS
- B, Transmitter-----1PCS
- C, Detachable Microphone-----1PCS
- D, Micro USB-USB short cable -----1PCS
- E, Micro USB-USB long cable -----1PCS
- F, Optical cable-----1PCS
- G, 2.5-3.5 Xbox cable -----1PCS
- H, 3.5-3.5 Xbox cable -----1PCS




②

2, Connection ports function :

Transmitter




- 1, Working indicating light
(*Flashing during pairing , solid blue light paired in use, solid red light while mic muted*)
- 2, Optical in
- 3, MICRO USB port



E


Headset

- 1, Recharging indicator light
- 2, USB recharging port
- 3, Power ON/OFF switch
- 4, 3.5mm X BOX interface
- 5, Stereo/Surround sound Switch
- 6, 3.5mm microphone interface
- 7, Chat sound VOL/MIC MUTE
- 8, Background VOL/PAIRING




3, Connection method :

First of all , connect Micro USB-USB long cable to DC 5V charging adaptor USB port to charge **A** headset for around 5 hours, red light on during charging and off after fully charge .




③


4, PS4 setting



1, Connect PS4 optical port with **B** Transmitter optical port **1** using **F** Optical cable (protection cover must be removed) ; Using **D** Micro USB short cable to connect PS4 USB port with **B** Transmitter **2** USB port as below :




2, Detail connection diagram :




3, PS4 console setting

1), After power on PS4 , choose setting



(4)

2), Choose Sound and Screen and press Enter



EN

3), Choose Audio Output Settings and press Enter



4), Choose Primary Output Port and press Enter



5), Choose DIGITAL OUT (OPTICAL) and press Enter




6), Remove tick mark in front of "Dolby Digital 5.1ch"、"DTS 5.1ch"



7), Choose Audio Format (Priority) and press Enter




8), Choose "Linear PCM and press Enter



(5)


9), Then choose setting and choose Devices and press Enter



10), Choose Audio Devices and press Enter



11), Choose Output to Headphones and press Enter



12), Choose Chat Audio and press Enter




4, Operation method:

- 1), Connect transmitter and PS4 console USB port using the short USB cable, light flashing .
- 2), Long press power button for 3 seconds to power on the headset , the headset should auto pair with the transmitter and solid blue light light up , if the headset light keep flashing , please pair them once again .
- 3), During pairing , please power on PS4 and do not play audio , place headset close to transmitter within 50 cm and long press mute button on headset for 5 seconds and release your finger when light keep fast flashing , then the light on transmitter and headset will become solid blue.
- 4), Default setting for mute is off (chat on), if you want to mute your chat voice , please press the mute button once and transmitter light will become red.
- 5), Volume adjusting switch allow you to adjust the game background and chat volume.


5, Common issue and solution

Common issue	Solution
1) Can't power on headset 2) Charging light off	1、 Long press power on button for 3 seconds 2、 Using USB cable to charge the headset , charging red indicating light on during charging and off after fully charge at about 5 hours charging
Power off after 10 mins	Fully charge headset for 5 hours before use
No background sound	1、 Optical cable not connected correctly , please remove protection cover and connect with right direction 2、 please make sure console setting will be :-Use HDMI cable to connect with PS4 and TV-Use fiber-optical cable to connect with PS4 and transmitter;- Use the USB cable to connect with the transmitter and USB port of PS4 : make sure the console setting is right also : Settings--Sound and Screen--Audio Output Settings--① Primary Output Port--DIGITAL Out(OPTICAL)--Delete ✓ “Dolby Digital 5.1ch” and “DTS 5.1ch” ② Audio Format (Priority)--Linear PCM Settings -- Devices -- Audio Devices -- Output to Headphones-- Chat Audio
No mic sound	1、 Plug in microphone for headset 2、 Use short USB cable for audio transmission 3、 Setting issue : Settings-Accessory Settings- Audio Device Settings-Input Device and Output Device Select all options: 5.8G Wireless headset ---OK 4、 Mic being muted , press the mute/pair button to active mic sound


5, PS3 setting



1, Connect PS3 optical port with **B** Transmitter optical port **1** using **F** Optical cable (protection cover must be removed) ; Using **D** Micro USB short cable to connect PS3 USB port with **B** Transmitter **2** USB port as below :




2, Detail connection diagram :




3, PS3 console setting

1), After power on PS3 console , select setting and choose Accessory Settings

(8)



2), Select Audio Device Settings



3), Set Input Device and Output Device to 5.8G Wireless headset , at this moment , you can set the microphone level and test the sound level when you wear the headset , you can set mic level from 1 to 5



4), Back to setting screen , select Sound Settings




5), Select Audio Output Settings



6), Select Optical Digital



7), Remove √ ticks of “Dolby Digital 5.1ch” and “DTS 5.1ch” and press Enter to confirm



8, Set Audio Multi-Output on



E

(9)