

VINCI MV Model VM6910

A Tablet Created for Families

With voice and data, to be shared for learning and for fun - for you to Inspire the Genius in Your Children!

Getting Started

Turn on your VINCI MV by pressing and holding the **POWER** button for 3 seconds. Wait till the system finishes starting up (about a minute).

Visit www.vincigenius.com to register your VINCI MV and to:

- Validate your warranty
- Obtain timely support
- Download free content

Charging

- Connect the MicroUSB head from the cable to the unit, arrow facing the back side (1).
- Keep the connector straight.
- Connect the USB end of the cable to the charger (2) plugged to the wall (3).
- It takes 4 hours to reach a full charge.



The Status Bar

	New email
	USB connected
	Return button
	Setting button & Display Recently-used application
	Current battery volume
	Airplane Mode On
	USB debugging connected
	Downloading
	Home button
	WIFI connected, Internet is available

Note: All the figures are for your reference only. These may be different from the actual display on your VINCI MV.

Specifications

Feature	VINCI MV Model VM6910
Voice	Quard-Band GSM
3G Data	WCDMA 850/1900/2100
WIFI	Yes
GPS	Yes
Bluetooth	Yes

Feature	VINCI MV Model VM6910
G-Sensor	Yes
CPU/GPU	Dual Core 1 GHz/SGX 531
RAM	1 GB
Internal Storage	8GB. External MicroSD up to 32GB
Battery	2800 mAH Li-On
Screen	1024 x 600 multi-touch 7"
Preloaded:	VINCI Curriculum App Samples, Kids Library App Samples, VINCI Music Video: 12 titles (approximately 30 minutes)
Included in the Pack- age:	Leather Case, Travel Charger, USB Cable, Earphone with microphone

Note 1: VINCI MV supports voice and data.

Note 2: WCDMA for 3G data service is valid in North America and certain regions of the world (AT&T, T-Mobile, Bell, Rogers etc.).

Note 3: Services are available where your SIM card is valid.



SIM & MicroSD Card Installation

- Turn off the unit and open the back cover around camera area
- Insert the SIM card or MicroSD card into the slot as indicated above
- Close the back cover and turn on power
- SIM with voice & 3G data to be inserted in the back slot . The front slot is voice only.

Data Connection

- If your SIM card comes with WCDMA 3G services, you can get online using the wireless network. Turn on 3G data service in SIM Card Management, under Settings.

Voice Service

- Enable voice services in SIM Card Management, under Settings.

GPS

- Access Location Services, under Settings, to enable GPS. **Tips:** It may take time to load the map when it is first used, or in a new region. Turn on A-GPS to speed up the process. It may be faster to update maps with Wi-Fi on.

WIFI

- Turn ON Wi-Fi by going to Settings. Follow the prompt to enter a password.

Bluetooth

- Under Settings, select an available Blue tooth device. Follow the prompt to enter a password and match the device in order to connect.

USB Connection

You can connect your VINCI MV to a PC via the USB cable to copy or move files, browse images and video files. After connecting VINCI MV to a PC, on the home screen of the phone, drag your finger to pull down the interface where you can turn on USB storage mode.

QUICK GUIDE

7 in. Family Tablet Model VM6910



V i N C I
Inspire the Genius

Technical Support:
www.vincigenius.com/support

Toll Free: 1-855-MY-VINCI
Email: support@vincigenius.com

Web Browsing

- In the browser interface tap the address bar
- Insert the correct URL (e.g., www.vincigenius.com), then tap **Start**

Install New Content



VINCI Curriculum
Central



VINCI Kids Library
Installer

You may install new apps through WIFI. **VINCI Curriculum** apps can be downloaded by visiting curriculum.vincigenius.com. You may also install additional **VINCI Kids Library** titles from kidslibrary.vincigenius.com.

WARNING: The inside of your VINCI MV contains fragile components. Do not twist, disassemble or drop from a high place or onto a hard surface. Avoid extreme heat and do not submerge in water.



Safety Precautions & Warranty

Warning:

- Do not use VINCI MV while charging
- Make sure the MicroUSB connector is positioned correctly to ensure proper charging
- Do not use liquids, chemicals or detergents to clean VINCI MV. Only use a dry, lint-free cloth

Return & Warranty:

- 12 months parts and labor only, except for the battery and screen. Please review the complete details of the Return and Warranty Policy at store.vincigenius.com/control/vincipolicy

Carrying Your Tab

When you are using the Tab, keep it at some distance (at least 2.5 cm away from your body). In case there is a need for slipcover, belt clip, or other accessories to carry your Tab, it is important to ensure these accessories are approved by the manufacturer. Otherwise, it may exceed the upper limit of radio frequency leakage.

Energy Leak of Radio Frequency

VINCI MV is a low-power, wireless transmitter and receiver. After being powered on, it will periodically send and receive radio signals while

its transmission power is controlled by the network. This device complies with local standards restricting energy leak of radio frequency.

Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

15.19 Labelling requirements.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

SAR tests are conducted using standard operating positions accepted by the FCC/IC with the phone transmitting at its highest certified power level in all tested frequency bands, although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value, in general, the closer you are to a wireless base station antenna, the lower the power output.

The SAR limit of (FCC/IC) is 1.6 W/kg averaged over one gram of tissue. Device type: BR07 has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for when properly worn on the body is 0.740W/kg.

This device was tested for typical body-worn operations with the back of the handset kept 1.0cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 1.0cm separation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly.

Non-compliance with the above restrictions may result in violation of RF exposure guidelines.