

***EXHIBIT C***  
***User Manual***

IMT-87CTA

1. Plug the edge of the transmitter into the auto-outlet with the other cord edge connected with cellular phone.

2. Hang up the receiver earphone at the proper location.

3. The transmitter keeps in charging condition toward the cellular phone as usual.

4. For receiving voice, the transmitter propagates signals through R/F to the receiver while incoming phone calls.

5. The receiver must be switched on while receiving calls. Power indicator (LED) will show on/off condition.

|                                   |         |                                                                      |                    |
|-----------------------------------|---------|----------------------------------------------------------------------|--------------------|
| Title:<br><b>Operation Manual</b> |         | Immortal-tek Enterprise Co., Ltd.                                    |                    |
| Drawn by: <b>Danney Sun</b>       |         | 10F1, No.333, Wen shing rd., Ku shan dist., Kaohsiung, Taiwan        |                    |
| Size: A4                          | Number: | Tel: 886-7-5528008                                                   | Fax: 886-7-5537983 |
|                                   |         | E-mail: <a href="mailto:imta23@inet.net">imta23@inet.net</a>         |                    |
|                                   |         | Home Page: <a href="http://www.imt.com.tw">http://www.imt.com.tw</a> |                    |
| File D:\Schmit-87\operation.sch   |         | Date: 28-Sep-2000                                                    | Time: 17:20:28     |
|                                   |         | Sheet: 1                                                             | of 1               |