

TUNE UP PROCEDURE

The PA's power out is factory set at 250W.

The following power adjustment procedure is provided for reference or verification purpose:

- Connect the PA's input port to a RF source.
- Connect the PA's output port to a 50Ohm, 250W load.
- Connect the PA's DC input to a 20A DC voltage source.
- Apply a 27VDC.
- Apply a RF frequency between 450-470MHZ and amplitude between 25 to 50W .
- Adjust the power out adjust pot located on the front panel for 250W.

