



PLAYTIME JUST GOT TUNED UP.



Howl!

With
lights and
sounds



Designed for indoor use only

RADIO 
Controlled MINI COUNTRYMAN
 **WOLF**



WOLF




With
lights and
sounds

TO REPLACE BATTERIES

- Removal and replacement of batteries should be carried out by an adult or under adult supervision. Uncover the single screw on the battery cover.
- Insert batteries as inserted correctly, observing the + and - marks on the battery compartment. Replace batteries using three "AAA" size 1.5v Alkaline batteries for the handset and three "AA" size 1.5v Alkaline batteries for the adapter.

- Replace battery cover and screw down.
- Do not use non-rechargeable batteries as they may be a fire and/or explosion hazard and can damage the typewriter.
- Do not attempt to charge non-rechargeable batteries. Do not use or clean the contacts in the battery compartment. Substandard batteries should be removed from the typewriter.
- Only batteries of the same or equivalent type as those specified should be used. Disposal of old batteries properly, never dispose of batteries in a fire. Recharge batteries after use of charging for long periods.
- Do not mix old (used) and new batteries or batteries of different types.
- Please return the above information for reference.
- After product is designed the batteries can be changed, because the battery cover can be removed.
- After following the instructions and checking the batteries the product does not function properly, please contact the dealer (Dear Products Ltd).
- Do not throw away the product or its components.

* The most common value associated with a nation.

 **GB TOYS** is a division of

For advice or information regarding this or any other Golden Bear product, please contact Golden Bear Products Ltd., Blackdown Hill, South Mimms, Herts. EN10 9AT.

WWW.GOLDENBEARTOYS.CO
Please recycle this packaging.



Information to user

A5 size

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.