




* Temperature is 10°C, 20°C (Base)




* Temperature is 30°C, 40°C (Base)




* Temperature is 50°C (Base)




* Temperature is -30°C, -20°C (Handset)




* Temperature is -10°C, 0°C (Handset)




* Temperature is 10°C, 20°C (Handset)




* Temperature is 30°C, 40°C (Handset)



* Temperature is 50°C (Handset)



9. BASE BANDWIDTH WITH MODULATION, HANDSET BANDWIDTH WITH MODULATION AND BASE WITH 2.5KHz TONE.

10. VERIFY CHANNELS AND FREQUENCIES

Verify the Frequency Pairs

Channel	Base (MHz)	Handset (MHz)	Channel	Base (MHz)	Handset (MHz)
1	925.08	902.58	31	926.28	903.78
2	925.12	902.62	32	926.32	903.82
3	925.16	902.66	33	926.36	903.86
4	925.20	902.70	34	926.40	903.90
5	925.24	902.74	35	926.44	903.94
6	925.28	902.78	36	926.48	903.98
7	925.32	902.82	37	926.52	904.02
8	925.36	902.86	38	926.56	904.06
9	925.40	902.90	39	926.60	904.10
10	925.44	902.94	40	926.64	904.14
11	925.48	902.98	41	926.68	904.18
12	925.52	903.02	42	926.72	904.22
13	925.56	903.06	43	926.76	904.26
14	925.60	903.10	44	926.80	904.30
15	925.64	903.14	45	926.84	904.34
16	925.68	903.18	46	926.88	904.38
17	925.72	903.22	47	926.92	904.42
18	925.76	903.26	48	926.96	904.46
19	925.80	903.30	49	927.00	904.50
20	925.84	903.34	50	927.04	904.54
21	925.88	903.38	51	927.08	904.58
22	925.92	903.42	52	927.12	904.62
23	925.96	903.46	53	927.16	904.66
24	926.00	903.50	54	927.20	904.70
25	926.04	903.54	55	927.24	904.74
26	926.08	903.58	56	927.28	904.78
27	926.12	903.62	57	927.32	904.82
28	926.16	903.66	58	927.36	904.86
29	926.20	903.70	59	927.40	904.90
30	926.24	903.74	60	927.44	904.94

Note : This is for sure that all frequencies are in 902MHz to 928MHz.

Section 15.214(d) The security code is set automatic:

Every time when you place the handset in the base, your cordless will randomly select one of 65,530 possible security codes.