

Open Button

- To unlock the vehicles doors when the button is pressed short.
- In case the button is pressed long the windows will open additionally.

Close Button

- Locks the vehicles doors when the button is pressed short.
- When the button is pressed long the windows will close additionally.
- To activate the power save mode when pressed twice. This mode is deactivated by pressing any button.

Trunk Button

To unlock and open the vehicles trunk lid.