



Model: XMTR12C FCC ID: 014XMTR12C
S/N: 10001 IC: 11556A-XMTR12C

This device complies with part 15 of the FCC Rules. Operation is
subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with
Industry Canada licence-
exempt RSS standards.
Cet appareil est conforme
aux normes RSS sans
licence de l'Industrie Canada.
(1) this device may not cause
interference and (2) this
device must accept any
interference, including
undesired operation of the
device.

La présent appareil est conforme
aux CNR d'Industrie Canada
applicables aux appareils radio
exemptés de licence. L'exploitation
est autorisée aux deux conditions
suivantes : (1) l'appareil ne
doit pas causer de brouillage, et
(2) l'utilisateur de l'appareil doit
accepter tout brouillage
radioélectrique subi, même si le
brouillage est susceptible d'en
compromettre le fonctionnement.



Model: XMTR12C FCC ID: 014XMTR12C
S/N: 10001 IC: 11556A-XMTR12C

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This device complies with the RSS-247 Class B limits for unlicensed operation in the 2.4 GHz ISM band. Operation is subject to the following two conditions:
(1) This device must not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique susceptible d'en compromettre le fonctionnement.





INSTANT-FIRE or NEXT-FIRE
Green=Safe Red=Armed

1 2 3

Four Flashes=High Battery

4 5 6

Three Flashes=Medium High Battery

7 8 9

Two Flashes=Medium Low Battery

10 11 12

One Flash=Low Battery

Pwr Rst Arm Next Fire

HOLATRON
InstantFire-12