

Model No. CE-251

Walkie Talkies

User Manual**HOW TO OPERATE YOUR TRANSCEIVER:**

1. Remove screw and open battery door and snap in a 9-V battery. (Battery is not included)
1. Turn on the transceiver by pushing the HI/LO/OFF switch to the HI or LO position. Your transceiver is now ready for transmitting.
2. Press the "PUSH TO TALK" button for transmitting
3. Release the "PUSH TO TALK" button for receiving
4. When transmitting, speak clearly in a normal voice, holding the set about 3" from your mouth.
5. Best transmission and reception are obtained when the antenna is held in a vertical position.

HOW TO USE MORSE CODE FUNCTION:

2. For transmitting a signal, turn on the transceiver by pushing the HI/LO/OFF switch to the HI or LO position.
3. While pushing the "PUSH TO TALK" button, press in the Morse code button momentarily and release for desired signals.
4. For receiving a signal, adjust volume by selecting the HI or LO position for desired level.
5. When back to voice communications again, use normal push-to-talk operation.

CAUTION:

1. Your transceiver set has been fully adjusted prior to shipment from the factory. Be sure not to touch the internal components other than replacing the battery.
2. When the sound becomes weak, it is time to change the battery.
3. After use, always return the HI/LO/OFF switch to the OFF position.
4. Keep your set in a dry and clean place.

Warning: Changes or modification to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help