

MODEL : CE233

WALKIE-TALKIES



4 Transistor with Morse Code key

CAUTION :

1. Your Transceiver Set has been fully adjusted prior to shipment from the factory. Do not touch the internal components other than replacing batteries.
2. When the sound becomes weak, it is time to change the battery.
3. After use, always return the "ON/OFF" Switch to the "OFF" position.
4. Keep your set in a dry and clean place.

HOW TO OPERATE YOUR TRANSCEIVER :

1. Open battery cover and snap in a "9-volt" battery.
2. Slide the "ON/OFF" switch to "ON" position. Your transceiver is now ready to operate.
3. Press the "PUSH-TO-TALK" switch for transmitting.
4. Release the "PUSH-TO-TALK" switch for receiving.
5. When transmitting, speak clearly in a normal voice.
6. Best transmission and reception are obtained when the antenna is held in a vertical position.

HOW TO USE MORSE CODE FUNCTION :

1. For transmitting a signal, slide the "ON/OFF" switch to "ON" position.
2. While pushing the "PUSH-TO-TALK" button, press the morse code button in momentarily and release for desired signals.
3. When back to communications again, use normal "PUSH-TO-TALK" operation.

