

INSTRUCTION

INTRODUCTION

HEADSET TWO WAVE COMMUNICATION SYSTEM IS JUST LIKE A CORDLESS TELEPHONE, IT ENABLES BOTH PARTIES TO TALK AT THE SAME TIME, ITS HEADSET STYLE ALLOWS YOUR HANDS TO BE FREE FOR OTHER ACTIVITIES.

HOW TO OPERATE YOUR TWO WAVE COMMUNICATION SYSTEM

1. UNSCREW WITH PHILLIPS SCREWDRIVER AND OPEN BATTERY DOOR, INSTALL 2 AA/UM3 BATTERIES ACORDING TO THE PROPER POLARITIES. CLOSE BATTERY COMPARTMENT DOOR AND BE SURE IT SNAPS SHUT PROPERTY.
2. SELECT LOW OR HIGH VOLUME BY USING THE SELECTOR SWITCH SITUATED AT THE SIDE OF YOUR COMMUNICATION SYSTEM. YOUR COMMUNICATION SYSTEM IS NOW READY TO OPERATE.
3. WHEN TRANSMITTING, SPEAK CLEARLY IN A NORMAL VOICE.
4. ADJUST HEADSET COMFORTABLE ON YOUR HEAD.
5. IN THE EVENT OF INTERFERENCE CAUSED BY OTHER RADIO SIGNAL IN THE VICINITY, MOVE TO A DIFFERENT LOCATION.

CAUTION

1. YOUR COMMUNICATION SYSTEM HAS BEEN FULLY ADJUSTED PRIOR TO SHIPMENT FROM THE FACTORY, BE SURE NOT TO TOUCH INTERNAL COMPONENTS OTHER THAN REPLACING BATTERIES.
2. WHEN THE SOUND BECOMES WEAK, IT IS TIME TO CHANGE THE BATTERIES.
3. AFTER USE, ALWAYS TURN THE SELECTOR SWITCH TO THE OFF POSITION.
4. KEEP YOUR COMMUNICATION SYSTEM IN A DRY AND CLEAN PLACE.

NOTE

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.