

INSTRUCTION BOOK '7' ENG (YC12) LENTEK

Size	20 8 x 14 8 mm
Material	10.5 Gsm AET Paper
Color	1+1

TWO YEAR LIMITED WARRANTY

Purchase Date: _____ ITEM# (above UPC code) _____

This Limited Warranty is effective upon purchase date. Please fill out the separate registration card and mail.

1. Lentek International warrants this product to be free of manufacturing defects. Should any such defect develop or become evident within TWO year from the date of purchase, Lentek International will replace the entire product or, at its option, repair or replace the defective part(s) without charge.

To Return Unit:

2. Securely pack the entire unit. Be sure the carton clearly identifies the sender by name and address. Attach a letter or card describing the nature of the defect. The original receipt of the purchase must be included in the returned package to be eligible for warranty coverage.

3. This warranty is void if the damage or malfunction is due to abuse or failure to operate the product in accordance with the instructions and/or on the recommended electrical current.

Mail prepaid via insured parcel post to:

LENTEK INTERNATIONAL, INC. •
3600 COMMERCE BLVD. • DOCK #7 • KISSIMMEE, FL 34741

**LENTEK INTERNATIONAL INC.**
3700 Commerce Blvd. • Kissimmee, FL 34741
Phone: 407-857-8786
Fax: 407-857-4045
Toll Free: 888-3LENTEK (353-6835)
Email: customerservice@lentek.com
www.lentek.com




© 2003 Lentek International. All rights reserved.
All specifications are subject to change without notice.

REVINSTYC12-0503

YC12

YardControl

Electronic Yard Fence



DIRECTIONS FOR USE

D A K A
MASTER COPY
正本文件

DOC#: 4030-YC1202121600
REV: A PG 1/4
APPROVED BY: 
DATE: 21 MAY 2003

D A K A

Dear Customer,

Thank you and congratulations on your purchase of this ingenious device. This product is the latest in new technology from Lentek™. Your satisfaction is very important to us.

Visit our website at: www.lentek.com and view the rest of our products, such as our Pet Appliance, Home Comfort, Wine Collection, Housewares and PestContro®. While you're there, register your new purchase, sign up to receive our newsletter, and learn more about our company.


Questions can also be asked on our website, or you can call: 1-888-3-LENTEK, or 407-857-8786 or contact your local Lentek dealer.

We look forward to serving you, now and in the future.

Enjoy!

Lou Lentine

Lou Lentine
President



NOTE

This unit has been tested and found to comply with Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this unit does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the unit and receiver.
- Connect the unit into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for assistance.

CARE & MAINTENANCE


- Do not operate this unit outdoors when using an AC adapter.
- Do not immerse this unit in water or any other liquid.
- Unplug before cleaning.
- Clean with water or a mild detergent only.
- Do not use harsh solvents on any part of this product.

INSTALLATION / MOUNTING:

Wall Mount




Fix the bracket to the wall or any vertical surface by using 3 long screws. Fasten the middle screw FIRST.



Use 2 short screws to attach the unit to the connector to the unit. Then put the unit onto the bracket. Turn the unit in the direction you want it to face.


Post Mount



• 4 •

PRODUCT DESCRIPTION

The YardContro+ is an unobtrusive sound generator that keeps stray and unwanted dogs, cats, deer, and other wild animals, and even humans out of your yard and gardens. The unit is equipped with a 360-degree motion detection sensory system that senses motion from all directions up to a 15-foot radius. It creates an invisible radar zone of approximately 700 sq. feet. When the unit detects an intrusion, it responds by emitting 129-decibel sound blast at 8kHz to deter the trespasser. Ultrasonic blasts of 101-decibel sound blast at 50kHz to deter the above-mentioned animals. When used as directed, the unit can effectively keep stray animals away.




HOW THE RADAR SYSTEM WORKS

Lentek's Radar Sensor System uses the latest in motion-sensing technology. After the unit is turned on, please allow 15-20 seconds for the system to activate. Once set, the radar motion detector will check for motion up to 15' in all directions every 5-10 seconds, sending out a preset ultrasonic sound pattern and activating the high-intensity xenon-effect strobe if movement is detected. Activation period may vary depending on factory settings.

CONTROL COVER

There is a control cover located on the top of the unit. It can be removed by giving it 1/8th of a turn clockwise, then lifting the cover off.



• 1 •

WARNING

HIGH OUTPUT SOUND WAVES CAN CAUSE HEARING DAMAGE. Be careful not to have your ears close to the unit. **DO NOT LET CHILDREN PLAY WITH TEST BUTTON.**

CONTROL PANEL

Demo/Test Button

The user can press this button to hear that the ultrasonic feature is working. This test enables the user to achieve the desired setting, and to confirm operation of the product. If the high frequency (50kHz) is being used, it is inaudible to humans, but it may produce a clicking sound. This clicking sound confirms proper operation.


OPERATION

Sensitivity Switch:

- Slide to HI for maximum coverage area (up to 15 feet from unit)
- Slide to LOW for smaller coverage area
- Adjust in-between for desired coverage area.

Frequency Adjustment:

Slide this control to set the ultrasonic frequency in the range most effective to repel your particular problem animal. The frequency range can be set from low (8kHz) to high (50kHz), providing an effective ultrasonic deterrent for most animals. Experiment and fine-tune the unit to determine which frequency works best in your target environment. *The Xenon-Effect Strobe will activate at any frequency.*



• 2 •

Note: For an audible intruder alarm, set the slide to the lowest frequency (8kHz).


Power Switch:

Switch to ON to activate the unit.


BATTERIES

The YardContro+ Electronic Yard Fence uses four "D" batteries (alkaline recommended), or an optional AC power adapter.

To install batteries



Battery Life: The batteries last at least 2,000 sound releases (10 seconds per sound release)



• 3 •