

SECURITY PROXIMETER

Never lose track of your portable valuables! Great for traveling!

Card size, easy to attach with your valuables in small size.

Attach the signal transmitter to your notebook computer, PDA pouch, wallet or any valuable items. Carry the receiver with you.

Selectable activation distance (Hi & Low) available

FEATURES:

- A precise, miniature electronic guarding system.
- Perfect for safeguarding your valuable items, including Cellular Phones, Notebooks, PDA, wallet, purse.... etc.
- Two different Hi & Low sensitivity available for different environment selection.
- The activating distance range between the RX & TX can be scoped to 3 meters or up to 13 meters!

PRODUCT INCLUDES:

- 1pc Transmitter (TX) (Attached to your valuable)
- 1pc Receiver (RX) (Attached to your person)
- 1pc double size foam

BATTERY INSTALLATION

1. Make sure the both units are in OFF position
2. Take out the battery drawer of RX/TX and insert CR2032 (included). (See Drawing)
3. Replace the battery drawer gently



OPERATING INSTRUCTIONS:

1. Turn on the RX unit. The red LED light will be on and you will hear a long beep followed by continuous short beeps. Now, the RX is ready to learn the TX code.
2. Turn on the TX unit. You will hear a fast beep signal consisting of one long and one short beep. After this, the beeping sounds will stop. This indicates that the RX has successfully learned the code. Both units' LED will blink continuously
3. If you still hear beeps after both RX & TX is on, then this might indicate that RX doesn't successfully learn the TX code. Please turn off both TX & the RX and start operation 1 & 2 again.
4. Once connecting RX & TX, attach the RX to person (i.e.: loop the strap on your hand or just put it into your pocket) and the TX to your valuable possessions (Cell phone, Notebook computer, wallet, etc.)
Base on the distance you want to guard your values, slide the switch on TX to LOW (short distance) or HI (long distance).
Select Hi if you want to set the guarding range with longer distance with longer or to select LOW to set the guarding distance with shorter distance.
Always test the units and select the suitable distance range (Hi or Low) based on your needs.
5. Separating the two units more than the distance you set, the RX will trigger 3 short beeps and sound continuously in order to remind you that you are away from your valuable.



Note:

- To follow its IC process, always turn on the RX first and the TX second.
- When you accidentally turn off either the RX or the TX during operation, you must turn off both units and start from the first steps of the operation as instructed above.
- Please keep the RX & the TX separated by at least 2/3 feet (20cm) during learning code status. This is the minimum distance required.
- Please replace battery if RX beep sounds become weak, or if the two units' responding distance becomes shorter.
- Always turn off both TX & RX to the off position when not in use.
- Do not use this device when on board an airplane.
- Do not use this device in the rain.

NOTE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.