



What 's in the box



Installation instructions

01 Connect to the TV

To enjoy picture quality in high resolution, we recommend you to use HDMI cable to connect iTalkBB set top box to your TV.

If you're not using a high resolution TV, please use AV cable to connect iTalkBB TV set top box to your TV (connecting with either HDMI cable or AV cable)

02 Connect to the internet

iTalkBB Chinese TV supports both wired and wireless netowrk. For wired connection, please plug network cable to the port before turning on the power. For wireless connection, turn on the power, then select your wifi name and input the password.

03 Start


iTalkBB TV set top box will automatically turn on once connected to the power.

Done!



For easy 2 steps, you are ready to enjoy live Chinese TV programs, unlimited movies and TV shows on demand.

Remark: The USB port of this product is used for connection of optional USB memory as a media player to play video or audio file. It cannot be used for connection of any computer.

Installation



Remote control function



* The accessories drawn in dotted lines are not included and are sold seperately.

Network settings

Network Settings

Wireless network

WIFI-01		
WIFI-02		
WIFI-03		
WIFI-04		
WIFI-05		
+ Other Network		

- > If you use wireless connection, then enter WIFI settings.
- > If you use wired network, already connect with network cable and network works well, then enter wired network settings.

A. Wireless Connection

- > Select your wifi name from the wireless network list, the lock icon means password needed.
- > Input password and then click "OK", it will automatically enter next step if connected.
- > Also you may manually add a wireless network if needed.

Network Settings

DHCP

IP Address

Subnet Mask

Gateway

DNS

Alternate DNS

[Next](#) [Back](#)

B. Wired Connection

- > Connect iTalkBB TV set top box to internet with a internet cable.
- > Simply click next for automatic configuration, and you're all set. You may also use manual IP configuration by turning on the DHCP button.

24 hours Hotline

USA,Canada 1-855-482-5588

Australia 1-800-248-255

Website

www.iTalkBB.com



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Powered by Beijing Capital Online Ltd.



FCC Statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radio and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.