

Data Set-up

By doing data setup, you can receive Internet data via satellite. For the physical connection, please refer to Fig 2, 3, and 4 in “How to use DTR5000N in the Satellite Network” in previous section. You should do data set-up after the Channel set-up




Fig 2. Data flow and routing for single IP address with direct connection