


Change PIN

PIN Code

You can change PIN number with this menu

- Select Change PIN menu from the MAIN menu.



- When you are asked to enter PIN Code, you enter current PIN Code. Then you will be asked for new PIN Code. You enter new PIN code, and the system re-asks you to repeat the PIN Code. If you enter the new PIN Code again, then the PIN code is permanently changed.
** Be sure not to forget the PIN code. If you forget the PIN Code, you have to contact the distributor to clear up the problem

