

Internal view of EUT - Shield Cover mounting state




Internal view of EUT - Shield cover Remove state



View of Main PCB(Top) - Shield Cover mounting state -1




View of Main PCB(Top) - Shield Cover mounting state -2




View of Main PCB(Bottom) -1



View of Main PCB(Bottom) -2



View of Main PCB(Bottom) -3



View of Battery(Top)



View of RF MODULE(Bottom)



View of RF MODULE(Top)



View of RF MODULE(Bottom)

