



DJB label and its dimension



The plate is under the battery  
in bottom side of the unit.

DJB label position