


UP-002BT

Package Content :



UP-002BT:




User's Manual :



USB Cable:



Features :



① Power LED Indicator

The LED indicator will be illuminated in BLUE to show the power status.

② Volume Button

Press + or - to adjust the volume.

③ Power / Pair Button

Press the Power button to turn on and pair with the speaker.

④ 3.5Ø Socket

The socket for connecting the right speaker.


⑤ Mini USB Port

⑥ 3.5Ø Plug


The plug for connecting the left speaker.

Instruction :


1 Unlock and twist the right and left speaker.



2 Pick up the 3.5mm plug from Right speaker, and connect to Left speaker.



3 Connect to your mobile phone, or computer.



Setup

To play audio from a Bluetooth device, you need to pair the device with the speaker. You can pair up to devices.

1. On your Bluetooth device, turn on Bluetooth and scan for devices in its Bluetooth menu.

2. **Power On/Off** : Push 3 seconds to turn on power

Pairing Mode : When powering up for the first time, push 6 seconds into pairing mode, the speaker is discoverable for 2 minutes and is ready for pairing. The Status indicator blinks red and blue.

Music NEXT / Previous Bottom : + continuous push / - continuous push

3. When "UP-002BT" appears on the searching list of your Bluetooth device, select the "UP-002BT". The Bluetooth status light turns solid blue after pairing is established. The speaker is ready to play music.

Note: If pairing times out (the Bluetooth status light stops blinking red and blue), press and hold the Pair/Power button to turn off UP-002BT. Then, repeat from step 2.

Charging :

Fully charge the speaker (about 4 hours).

1. Plug the charging cable into the speaker's charging port and the other end into computer USB port (with the power on) for charging.

Status indicator :

• **Pairing Mode** : Blue/Red light switch


• **Normal Working** : Blue light ticking

• **Play Music** : Blue light on

• **Power Shortage** : Red light ticking

• **Charging** : Red light on

The speaker enters power saving mode if no bluetooth signal for 2 minutes. UP-002BT will automatically turn off.



Troubleshooting :

The speaker doesn't work or it won't pair

- Try moving your device closer.
- Is the speaker turned on and charged?
- Turn the speaker off and then on to wake it.
- Is Bluetooth enabled on your device or computer?
- Try repeating the setup procedure in this guide or pair with a different Bluetooth device.
- The speaker plays music from one device at a time. Unpair the device not being used. (Refer to your device documentation for help.) Pair a new device using the setup procedure.
- If pairing with a computer, specify the UP-002BT as the audio out device on the computer.
- When disconnect the pairing, shoud also remove UP-002BT from your searching list.

Maintenance :

Under the condition of normal use, please use dry cloth to clean the appearance of speaker. If necessary, please use cloth with diluted detergent to clean it. It is prohibited to use wax, detergent, thinner, gasoline, insecticide or chemical reagent because of causing corrosion on the surface of the product.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.