


颜色：银底黑字+Pantone Reflex Blue C



A top-down diagram of the rear of the device. It shows a large rectangular battery compartment with a latch on the left side. A red line points to the latch. There are four circular screws or fasteners around the perimeter of the battery compartment. The entire device is enclosed in a rounded rectangular frame.