

APPENDIX D – DUT AND ACCESSORY PHOTOS

Figure	XL-185P Radio						
7							
Front		Back		Left		Right	
w/o Antenna		w/o Antenna		w/o Antenna		w/o Antenna	
							
Top				Bottom			
w/o Antenna							
							

Figure: 8

Accessory Photo

Part Number

14035-4010-04 Li_Ion Battery Pack

Front View



Back View



Figure: 9

Accessory Photo

Part Number

14035-4010-01 Li_Ion Battery Pack

Front View



Back View



Figure: 10

Accessory Photo

Part Number

12082-0600-01 Standard Speaker Microphone



Figure: 11

Accessory Photo

Part Number

14002-0197-01 Hirose to Unity Adapter



Figure: 12

Accessory Photo

Part Number

12150-1000-01 Premium Speaker MIC, Fire, NC






Figure	14002-0218-01 Leather Belt Loop w/ 12082-3230-01 D-Swivel	
16		
Front		
		
Back		
		
Side		
		

Figure	KRY 101 1609/1 Leather Belt Loop w/ 12082-3230-01 D-Swivel	
17		
Front		
		
Back		
		
Side		
		

Figure	12082-1290-01 Belt Clip
18	
Front	
	