


Diagram illustrating the back of the device with the following components labeled:

- QR Code Card (Insert from top to bottom)
- Reset key
- SIM Card slot
- Power key
- Volume+
- Volume-
- Function key
- Status indicator
- Type C USB



Components Name	Quantity
Device	1
Type C USB power cable	1
Instructions (warranty card, certificate of conformity)	1

Please cut down this card along the dotted line

- ① Before power on, please confirm whether the 4G SIM card (mini card) has been correctly inserted into the SIM card slot;
- ② Press and hold the power key to start the Q181 SE. After the Q181 SE is started, it will automatically connect to the 4G network to receive transaction information and broadcast;
- ③ Do not pull out the SIM card during startup.

	Power key	+	-	Function key	RESET
Long press	Power on/off	inapplicability	inapplicability	Network status	System reset
Short press	Broadcast the value of battery power	volume up	volume down	Broadcast the last transaction	System reset

-3-

-4-

-5-

Address: 3/F, No.2 Building, Aisino Information Park, No.18A,
Xingshikou Road, Haidian District, Beijing.
Zip Code: 100195.
Email: info@vanstone.com.cn
Manufacture Name: Vanstone Electronic(Huizhou) Co.,Ltd.
Manufacture Address: 4/F, No.12 Building, Aerospace Science
And Technology industrial Park, No. 51, Zhongkai Road, Huizhou
City, Guangdong Province, China.
Company Website: <https://www.vanstone.com.cn/en>

- 6 -

- 7 -

- 8 -

- 9 -

The pictures and descriptions in this guide are for reference only, please prevail in kind.