

PACKAGE CONTENTS

- Razer Orochi Gaming Mouse
- 2x AA Battery
- USB Cable
- Travel Pouch
- Quick Start Guide

HARDWARE & SYSTEM REQUIREMENTS

- Bluetooth® enabled PC/MAC with USB Port
- Windows™ 7 / Windows Vista™ / Windows XP or Mac OS X (10.6 to 10.7)
- Internet connection
- 100MB of free hard disk space

© 2014 RAZER, INC. RAZER™ IS A REGISTERED TRADEMARK OF RAZER, INC.

SETTING UP YOUR RAZER OROCHI

(WIRELESS MODE)

1. Remove the top cover of the Razer Orochi.
2. Insert the batteries into the Razer Orochi following the directions indicated.
3. Reattach the top cover onto the Razer Orochi. Please ensure it is secured.
4. Switch on the Razer Orochi.

www.razer.com © 2014 RAZER, INC.

Page 4

Page 5

5. Please ensure that Bluetooth is activated on your PC / Mac. Add a Bluetooth device by following the instructions for your operating system. Activate the pairing process by pressing **all four side buttons together** on the Razer Orochi for **five seconds**. The indicator lights on the top of the Razer Orochi will blink in blue to indicate the pairing process.

6. When the pairing process is completed, the indicator light will stop blinking. Your Razer Orochi is then ready for use in wireless mode.

BATTERY INDICATOR BEHAVIOR

31% to 100% Battery	Green LED
11% to 30% Battery	Red LED
Below 10% Battery	Red blinking LED
Bluetooth pairing mode	Green blinking LED

NOTE: To conserve power, switch off the Razer Orochi when not in use.

© 2014 RAZER, INC. RAZER™ IS A REGISTERED TRADEMARK OF RAZER, INC.

IMPORTANT NOTE:
Scroll button light is off by default. You can turn it on in the LIGHTING AND MAINTENANCE TAB.

(WIRED MODE)

1. Connect the micro-USB end of the cable to the Razer Orochi.
2. Plug the mouse into the USB port of your computer. The Razer Orochi is then ready for use as a high performance wired gaming mouse.

www.razer.com © 2014 RAZER, INC.

Page 6

PAGE 6: 4C COLOR PRINT!!!!!!!!!!!!

Page 7

INSTALLATION / REGISTRATION / TECHNICAL SUPPORT

INSTALLATION

1. Plug the USB cable from your Razer Orochi to your computer.
 2. Download the Razer Synapse 2.8 installer from www.razer.com.
 3. Run the installer and follow the onscreen instructions.
 4. Register for a Razer Synapse 2.8 account and confirm your new account.
 5. Open Razer Synapse 2.8 and login to your account.
 6. Wait until the software automatically downloads and installs.
- Please refer to the Razer Synapse 2.8 user guide at www.razer.com for in-depth instructions on how to configure and use your Razer Orochi.

REGISTRATION

1. Register for a Razer Synapse 2.8 account at www.razer.com.
2. Confirm your email address by clicking the link in the email you receive from Razer.

TECHNICAL SUPPORT

- What you'll get:
- 2 years limited manufacturer's warranty
 - Free online technical support at www.razer.com

© 2014 RAZER, INC. RAZER™ IS A REGISTERED TRADEMARK OF RAZER, INC.

FRANÇAIS

CONTENU DU PACK

- Souris de jeu Razer Orochi
- 2 piles AA
- Câble USB
- Guide de démarrage rapide

REQUIS DE SYSTÈME

- Ordinateur personnel avec port USB
- Windows 7 / Windows Vista / Windows XP
- Connexion Internet
- 100 Mo d'espace libre sur le disque dur

INSTALLATION

1. Branchez le câble USB de la souris Razer Orochi sur votre ordinateur.
2. Téléchargez l'installateur Razer Synapse 2.8 à partir de www.razer.com.
3. Exécutez l'installateur et suivez les instructions à l'écran.
4. Créez un compte Razer Synapse 2.8 et confirmez votre nouveau compte.
5. Ouvrez Razer Synapse 2.8 et connectez-vous à votre compte.
6. Attendez que le logiciel télécharge et installe automatiquement les pilotes et le logiciel.

vingt secondes. L'installation terminée, un message de la Razer Orochi apparaît sur votre ordinateur pour le processus de configuration et de mise à jour. Cliquez sur le bouton de configuration et de mise à jour. Vous Razer Orochi peut désormais être utilisé en mode filaire.

INSTALLATION / RÉGISTRATION / SOUTIEN TECHNIQUE

1. Branchez le câble USB de la souris Razer Orochi sur votre ordinateur.
2. Téléchargez l'installateur Razer Synapse 2.8 à partir de www.razer.com.
3. Exécutez le programme d'installation et suivez les instructions à l'écran.
4. Créez un compte Razer Synapse 2.8 et confirmez votre nouveau compte.
5. Ouvrez Razer Synapse 2.8 et connectez-vous à votre compte.
6. Attendez que le logiciel télécharge et installe automatiquement les pilotes et le logiciel.

ENREGISTREMENT

1. Enregistrez-vous pour un compte Razer Synapse 2.8 sur www.razer.com.
2. Confirmez votre adresse e-mail en cliquant sur le lien dans l'e-mail que vous recevez de Razer.

ASSISTANCE TECHNIQUE

- Qu'est-ce que vous allez recevoir :
- 2 ans de garantie limitée du fabricant
 - Soutien technique en ligne gratuit 24 heures sur 24

© 2014 RAZER, INC. RAZER™ IS A REGISTERED TRADEMARK OF RAZER, INC.

Page 8

Page 9