

Universal FM Hands Free ~ Easy - talk

Operation Description:

Insert the plug into the car lighter and set your car radio channel to be FM 96.0MHz. When the phone ring and the signal effective, the car audio system immediately stop to become the phone ring voice. The sound volume transfer from the car speaker. When the phone conversation terminated, the car audio system reverts to the origin within 15 seconds.