

# Wireless Audio Link

## **Introducing the Wireless Audio Link**

The Wireless Audio Link plays music from any portable Audio device or computer on any FM equipped stereo Source. Wirelessly transmits the audio using FM frequencies. No batteries required.

## **Features and Benefits**

- Modulation : FM from 88.1 to 88.9 MHZ
- Channel: 5 channels.
- Distance: 10 meters.
- 5V supplied voltage at 22 mA current.
- Power requirement: USB Bus Power or External Power. (for Mobile model only ).

## **Requirements**

- A powered USB port

## **Package Contents Available**

- (1) Wireless Audio
- (2) Audio cable
- (3) Car power adapter

## **Installation**

1. Connect this unit to a USB port for power. Make sure the USB port actually has power.
2. Insert one end of the audio cable into the unit. Only one end fits this jack.
3. Insert the other end of the audio cable to your audio source's output jack.
4. Adjust the frequency on your FM equipped audio device to match the Wireless Audio Link's. The default frequency is set at 88.1 MHZ.
5. You should now hear music from your audio source in your FM equipped audio device. Turn on the volume if necessary.