








NTNV-n41-PC2-30-70-M-CP-QPSK-Outer_Full-Ant1-PASS

NTNV-n41-PC2-30-70-M-CP-16QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-70-M-CP-64QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-70-M-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-70-H-DFT-BPSK-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-70-H-DFT-QPSK-Outer_Full-Ant1-

PASS





NTNV-n41-PC2-30-70-H-DFT-16QAM-Outer_Full-Ant1-

PASS


NTNV-n41-PC2-30-70-H-DFT-64QAM-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-70-H-DFT-256QAM-Outer_Full-Ant1-PASS

NTNV-n41-PC2-30-70-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-70-H-CP-16QAM-Outer_Full-Ant1-PASS

NTNV-n41-PC2-30-70-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-70-H-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-80-L-DFT-BPSK-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-80-L-DFT-QPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-80-L-DFT-16QAM-Outer_Full-Ant1-
PASS






NTNV-n41-PC2-30-80-L-CP-64QAM-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-80-L-CP-256QAM-Outer_Full-Ant1-

PASS





NTNV-n41-PC2-30-80-M-DFT-BPSK-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-80-M-DFT-QPSK-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-80-M-DFT-16QAM-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-80-M-DFT-64QAM-Outer_Full-Ant1-


PASS




NTNV-n41-PC2-30-80-M-DFT-256QAM-Outer_Full-Ant1-

PASS


NTNV-n41-PC2-30-80-M-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-80-M-CP-16QAM-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-80-M-CP-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-80-M-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-80-H-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-80-H-DFT-QPSK-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-80-H-DFT-16QAM-Outer_Full-Ant1-

PASS





NTNV-n41-PC2-30-80-H-DFT-64QAM-Outer_Full-Ant1-


PASS




NTNV-n41-PC2-30-80-H-DFT-256QAM-Outer_Full-Ant1-



PASS



NTNV-n41-PC2-30-80-H-CP-QPSK-Outer_Full-Ant1-PASS


NTNV-n41-PC2-30-80-H-CP-16QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-80-H-CP-64QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-80-H-CP-256QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-L-DFT-BPSK-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-90-L-DFT-QPSK-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-90-L-DFT-16QAM-Outer_Full-Ant1-
PASSNTNV-n41-PC2-30-90-L-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-L-DFT-256QAM-Outer_Full-Ant1-PASS

NTNV-n41-PC2-30-90-L-CP-QPSK-Outer_Full-Ant1-PASS





NTNV-n41-PC2-30-90-L-CP-16QAM-Outer_Full-Ant1-PASS

NTNV-n41-PC2-30-90-L-CP-64QAM-Outer_Full-Ant1-PASS





NTNV-n41-PC2-30-90-L-CP-256QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-M-DFT-BPSK-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-90-M-DFT-QPSK-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-M-DFT-16QAM-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-90-M-DFT-64QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-M-DFT-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-M-CP-QPSK-Outer_Full-Ant1-PASS

NTNV-n41-PC2-30-90-M-CP-16QAM-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-90-M-CP-64QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-M-CP-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-H-DFT-BPSK-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-H-DFT-QPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-90-H-DFT-16QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-H-DFT-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-H-DFT-256QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-90-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n41-PC2-30-90-H-CP-16QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-H-CP-64QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-90-H-CP-256QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-DFT-BPSK-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-L-DFT-QPSK-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-100-L-DFT-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-DFT-64QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-L-DFT-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-L-CP-QPSK-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-100-L-CP-16QAM-Outer_Full-Ant1-

PASS





NTNV-n41-PC2-30-100-L-CP-64QAM-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-100-L-CP-256QAM-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-100-M-DFT-BPSK-Outer_Full-Ant1-

PASS

NTNV-n41-PC2-30-100-M-DFT-QPSK-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-100-M-DFT-16QAM-Outer_Full-Ant1-

PASS


NTNV-n41-PC2-30-100-M-DFT-64QAM-Outer_Full-Ant1-

PASS



NTNV-n41-PC2-30-100-M-DFT-256QAM-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-100-M-CP-QPSK-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-100-M-CP-16QAM-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-100-M-CP-64QAM-Outer_Full-Ant1-

PASS




NTNV-n41-PC2-30-100-M-CP-256QAM-Outer_Full-Ant1-
PASS





NTNV-n41-PC2-30-100-H-DFT-BPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-H-DFT-QPSK-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-H-DFT-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-H-DFT-64QAM-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-100-H-DFT-256QAM-Outer_Full-Ant1-
PASS




NTNV-n41-PC2-30-100-H-CP-QPSK-Outer_Full-Ant1-
PASS

NTNV-n41-PC2-30-100-H-CP-16QAM-Outer_Full-Ant1-
PASS



NTNV-n41-PC2-30-100-H-CP-64QAM-Outer_Full-Ant1-

PASS



NTNV-n41-PC2-30-100-H-CP-256QAM-Outer_Full-Ant1-

PASS