



NTNV-n77(3450-3550)-PC2-30-15-L-DFT-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-DFT-16QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-15-L-DFT-64QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-DFT-256QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-L-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-BPSK-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-15-M-DFT-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-64QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-M-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-DFT-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-DFT-16QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-15-H-DFT-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-15-H-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-DFT-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-DFT-16QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-20-L-DFT-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-20-L-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-L-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-DFT-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-DFT-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-DFT-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-QPSK-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-20-M-CP-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-64QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-M-CP-256QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-BPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-64QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-20-H-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-DFT-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-DFT-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-DFT-64QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-25-L-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-L-CP-64QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-25-L-CP-256QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-DFT-BPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-DFT-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-DFT-16QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-25-M-DFT-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-DFT-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-CP-16QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-25-M-CP-64QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-M-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-DFT-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-DFT-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-DFT-64QAM-  
Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-25-H-DFT-256QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-CP-QPSK-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-CP-16QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-CP-64QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-25-H-CP-256QAM-  
Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-DFT-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-DFT-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-DFT-64QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-L-DFT-256QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-L-CP-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-CP-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-L-CP-64QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-L-CP-256QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-DFT-BPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-DFT-QPSK-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-DFT-16QAM-Outer\_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-DFT-64QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-M-DFT-256QAM-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-M-CP-QPSK-Outer\_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-30-M-CP-16QAM-Outer\_Full-Ant1-PASS