




NTNV-n77(3450-3550)-PC2-30-30-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-M-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-BPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-30-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-BPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-DFT-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-L-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-DFT-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-40-M-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-M-CP-64QAM-Outer_Full-Ant1-PASS




NTVN-n77(3450-3550)-PC2-30-40-M-CP-256QAM-Outer_Full-Ant1-PASS




NTVN-n77(3450-3550)-PC2-30-40-H-DFT-BPSK-Outer_Full-Ant1-PASS




NTVN-n77(3450-3550)-PC2-30-40-H-DFT-QPSK-Outer_Full-Ant1-PASS



NTVN-n77(3450-3550)-PC2-30-40-H-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-H-DFT-64QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-40-H-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-40-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-L-DFT-BPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-50-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-L-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-L-DFT-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-L-DFT-256QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-50-L-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-L-CP-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-L-CP-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-50-L-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-DFT-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-DFT-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-CP-QPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-50-M-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-M-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-DFT-BPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-50-H-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-DFT-64QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-50-H-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-50-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-DFT-BPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-DFT-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-DFT-16QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-60-L-DFT-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-CP-16QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-60-L-CP-64QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-L-CP-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-DFT-BPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-DFT-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-DFT-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-DFT-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-CP-QPSK-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-60-M-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-CP-64QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-M-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-DFT-BPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-DFT-QPSK-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-DFT-16QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-DFT-64QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-60-H-DFT-256QAM-
Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-CP-QPSK-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-CP-16QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-60-H-CP-64QAM-Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-60-H-CP-256QAM-Outer_Full-Ant1-PASS




NTNV-n77(3450-3550)-PC2-30-70-L-DFT-BPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-70-L-DFT-QPSK-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-70-L-DFT-16QAM-
Outer_Full-Ant1-PASS



NTNV-n77(3450-3550)-PC2-30-70-L-DFT-64QAM-
Outer_Full-Ant1-PASS